

Jayco 1st Service Carry out 1,000km/3-Month Service (Whichever comes first) as per Jayco Service Manual

Travel Components

Wheels & Tyres

- ✓ Check tyre condition and pressures

Brakes

- ✓ Check operation

Lights

- ✓ Test indicators
- ✓ Test brake lights
- ✓ Test tail lights/number plate lights
- ✓ Test side markers

RV Operation Components

Check Security and operation (on Gas/12V/240V where applicable) of the following items:

- ✓ Fridge – also check flue
- ✓ Gas Heater – also check flue & remote
- ✓ Air conditioner – also check remote
- ✓ Generator - Inspect generator slide and fuel connections
- ✓ Microwave
- ✓ Oven/Griller
- ✓ Stereo System - also check head unit/CD player/speakers
- ✓ Slide out BBQ
- ✓ Hot water service

240V Electrical

- ✓ Inspect circuit breaker
- ✓ Inspect 240V inlet/outlet
- ✓ Inspect 240V power point

12V Electrical

- ✓ Check battery charging operation
- ✓ Inspect int/ext 12V socket
- ✓ Check internal lights
- ✓ Check annexe/ROA/Grab handle light

Television Entertainment

- ✓ Check operation of windup antenna
- ✓ Check operation of TV / remote
- ✓ Inspect TV bracket, tighten if req'd
- ✓ Check operation of satellite system

Plumbing System

Mains Pressure / 12V Pump

- ✓ Check pressure mains & 12V Pump
- ✓ Inspect 12V pump and filter
- ✓ Check int taps & shower
- ✓ Inspect intl water pipes for kinks
- ✓ Inspect under body hoses for kinks

Slide out System

- ✓ Check operation of Slide out

Miscellaneous Safety

- ✓ Check operation of smoke alarm
- ✓ Inspect fire extinguisher

Waste

- ✓ Inspect waste outlet & pipes to all sinks
- ✓ Inspect waste outlet to shower

Grey/Water tanks

- ✓ Check inlets for clearance
- ✓ Check tanks for leaks at welds & sensors

Awning

- ✓ Check operation of ROA
- ✓ Re-tension ROA if required

Gas System

- ✓ Inspect under body gas pipes
- ✓ Inspect Gas bayonet (if fitted)

Furniture

- ✓ Check Security
- ✓ Check drawer runners
- ✓ Adjust latches and hinges as required

Preventative Maintenance

Exterior sealant

- ✓ Inspect roof sealant
- ✓ Inspect window sealant
- ✓ Inspect accessory sealant

Front Boot

- ✓ Inspect seals/screws
- ✓ Check operation of stays
- ✓ Lubricate locks

Windows

- ✓ Inspect Seals/screws
- ✓ Check operation of stays & lube
- ✓ Check operation of blinds

Moisture Test

- ✓ Visual moisture check throughout RV

Doors

- ✓ Inspect Seals/screws/hinges
- ✓ Check alignment
- ✓ Lubricate locks

Picnic Table

- ✓ Inspect screws & lubricate locks, Orings

Jayco Annual Service Carry out 10,000km/12-Month Service (Whichever comes first) as per Jayco Service Manual

Travel Components

Wheels & Tyres

- ✓ Check tyre condition and pressures

Brakes

- ✓ Check operation

Lights

- ✓ Test indicators
- ✓ Test brake lights
- ✓ Test tail lights/number plate lights
- ✓ Test side markers

RV Operation Components

Check Security and operation (on Gas/12V/240V where applicable) of the following items:

- ✓ Fridge – also check flue
- ✓ Gas Heater – also check flue & remote
- ✓ Air conditioner – also check remote
- ✓ Generator - Inspect generator slide and fuel connections
- ✓ Microwave
- ✓ Oven/Griller
- ✓ Stereo System - also check head unit/CD player/speakers
- ✓ Slide out BBQ
- ✓ Hot water service – replace anode

240V Electrical

- ✓ Inspect circuit breaker
- ✓ Inspect 240V inlet/outlet
- ✓ Inspect 240V power point

12V Electrical

- ✓ Check battery charging operation
- ✓ Inspect int/ext 12V socket
- ✓ Check internal lights
- ✓ Check annexe/ROA/Grab handle light

Television Entertainment

- ✓ Check operation of windup antenna
- ✓ Check operation of TV / remote
- ✓ Inspect TV bracket, tighten if req'd
- ✓ Check operation of satellite system

Plumbing System

Mains Pressure / 12V Pump

- ✓ Check pressure mains & 12V Pump
- ✓ Inspect 12V pump and filter
- ✓ Check int taps & shower
- ✓ Inspect intl water pipes for kinks
- ✓ Inspect under body hoses for kinks

Slide out System

- ✓ Check operation of Slide out

Miscellaneous Safety

- ✓ Replace smoke alarm battery & check operation
- ✓ Inspect fire extinguisher

Waste

- ✓ Inspect waste outlet & pipes to all sinks
- ✓ Inspect waste outlet to shower

Grey/Water tanks

- ✓ Check inlets for clearance
- ✓ Check tanks for leaks at welds & sensors

Awning

- ✓ Check operation of ROA
- ✓ Re-tension ROA if required

Gas System

- ✓ Inspect under body gas pipes
- ✓ Inspect Gas bayonet (if fitted)

Furniture

- ✓ Check Security
- ✓ Check drawer runners
- ✓ Adjust latches and hinges as required

Compliance

- ✓ Inspect VIN plate
- ✓ Inspect VIN number to A Frame

Preventative Maintenance

Exterior sealant

- ✓ Inspect roof sealant
- ✓ Inspect window sealant
- ✓ Inspect accessory sealant

Front Boot

- ✓ Inspect seals/screws
- ✓ Check operation of stays
- ✓ Lubricate locks

Windows

- ✓ Inspect Seals/screws
- ✓ Check operation of stays & lube
- ✓ Check operation of blinds

Moisture Test

- ✓ Visual moisture check throughout RV

Doors

- ✓ Inspect Seals/screws/hinges
- ✓ Check alignment
- ✓ Lubricate locks

Picnic Table

- ✓ Inspect screws & lubricate locks, Orings